

Midi cartridge for prophet64

The buyer of this cartridge is purchasing a product designed for a computer no longer manufactured nor carried by distributors.

The buyer is to be aware that though all units are carefully quality checked before shipping, the providing party can not guaranty a proper functioning of its products due to the platform running it where errors because of age, malfunction circuits and/or other factors occur. Therefore, this cartridge is provided as is, without any kind of warranty. Dtronics shall in no event be liable for any loss of data or damage to either machine and/or cartridge. The buyer is advised to thoroughly read the instructions provided in this manual.

Installing the cartridge

Make sure the power is OFF!

Insert the cartridge with the components faced up.

Make sure you have the prophet64 cartridge installed, never use the cartridge without the prophet64 installed!!

Turn on the power. The led should flash 3 times now, showing the cartridge is ready and running.

Using the cartridge

We advice to use the port-test function of the prophet64 to test the sync and program-change functions.

- Midi to prophet64

When a midi timing signal is received, the led on the cartridge will flash in sync with the midi signal.

The midi-out connector will function as midi-thru.

The cartridge will respond to program change messages on channel 16, you can use program change numbers 0 to 31. (Use the prophet64 port-check function to test your setup)

- Prophet64 to midi

You can use the cartridge to sent out a midi timing signal from the C64

In order to do this, turn the c64 off and back on with no midi-in connectors attached. The led will flash in sync to indicate the timing signal.

The cartridge will not sent any program changes.



